



This antenna bracket is for installation on these specific vehicles:

Ford Explorer	2020 +
(Install instructions on reverse side)	
Chevrolet Silverado 1500:	2014-2019
Silverado 2500, 3500:	2016-2019
GMC Sierra 1500:	2014-2019
GMC Sierra 2500, 3500:	2016-2019

Tools Required:

13mm socket and driver, or 13mm box end wrench

Install location:

Left front fender

Model#: CV2ANTNCG



Please Read: Always check for continuity between the bracket and chassis ground. If there is a problem with grounding, place the provided star washer between the bracket and the fender.

Step 1) Set the parking brake. Open hood and locate 13mm bolt near the back of the front fender. Remove bolt.

Step 2) Align the antenna bracket with the bolt hole. Reinstall the bolt and tighten.

Step 3) Insert the NMO or required connector to mate with the antenna and tighten securely keeping in mind that NMO mounts are designed to be installed from the top.



NCG Company may not be held liable for any damage to the vehicle before, during or after the installation or removal of this antenna bracket.
NCG may not be held liable for any personal injury resulting from accident or improper installation.



National Communications Group Co., Ltd
Chino, CA 800-962-2611
909-393-6133 Fax: 909-393-6136
www.natcommgroup.com



**Installation instructions for the 2020
FORD EXPLORER**

Model#: CV2ANTNCG

Tools Required:

10mm socket and driver, or 10mm box end wrench

Install location:

Left front fender



The fender bolt is located under the panel at the front left corner of the engine compartment.



Remove the clips that hold the panel in place to gain access to the fender bolt. Once the bracket is installed and bolted down, replace the clips that hold the panel in place.

Please Read: Always check for continuity between the bracket and chassis ground. If there is a problem with grounding, place the provided star washer between the bracket and the fender.

Step 1) Set the parking brake. Open hood and locate the 10mm bolt near the windshield of the front drivers side fender. Remove bolt.

Step 2) Align the antenna bracket with the bolt hole. Reinstall the bolt and tighten.

Step 3) Insert the NMO or required connector to mate with the antenna and tighten securely keeping in mind that NMO mounts are designed to be installed from the top.



NCG Company may not be held liable for any damage to the vehicle before, during or after the installation or removal of this antenna bracket.
NCG may not be held liable for any personal injury resulting from accident or improper installation.



National Communications Group Co., Ltd
Chino, CA 800-962-2611
909-393-6133 Fax: 909-393-6136
www.natcommgroup.com